



# MULTIPROP MP 120, 250, 350, 480, 625 Slab Props

Instructions for Assembly and Use – Standard Configuration – Edition 07/2017





# Content

## Introduction

Overview, main components	1
Standard configuration	2
Intended use	2
Safety instructions	3
General	3

## Standard configuration

A1	Assembly	
	Pre-assembling the slab prop	4
	Assembly with Universal Tripod	6
A2	Dismantling	
	Releasing the slab prop under load	7
A3	Accessories	
	Brace Clamp	8
	Base MP 50	9
A4	Foreseeable misapplications	10
A5	Storage and Transportation	13

## Tables

Permissible prop loads	
MULTIPROP MP 120, 250, 350, 480, 625	14
MULTIPROP MP 120, 250, 350, 480, 625 with Base MP 50	16

## Components

Components	18
------------	----

### Key



Safety instructions



Note



Visual check



Tip




Load-bearing point

# Introduction

## Overview, main components


### MULTIPROP MP

- 1 Outer Tube
- 2 Inner Tube
- 3 Securing Hook
- 4 Adjusting Collar
- 5 Pressure Spring
- 6 Measuring Tape
- 7 Rubbing Plate
- 8 End Plate



### Base MP 50

- 11 Base MP 50
- 11a Head Plate
- 11c Clamping Claw
- 11b Centering Pin



# Introduction

## Standard configuration

### Area of application

MULTIPROP Slab Props

- are props made of aluminium,
- correspond to the load requirements of DIN EN 16031,
- are used as vertical supports for temporary constructions.

### Features

MULTIPROP slab props are used in shoring operations in a planned perpendicular position for the transfer of vertical loads. In particular, they also provide support for slab formwork systems. The outer tubes of the MULTIPROP Slab Props are powder coated. The integrated measuring tape and free-running collar allow accurate and fast height adjustment. The height is continuously adjustable by means of the end-to-end thread without pegging. The MULTIPROP Slab Prop has a fail-safe feature which prevents the inner tube from unintentionally slipping out.

### Main components

MULTIPROP

- MP 120, L = 0.80 – 1.20 m
- MP 250, L = 1.45 – 2.50 m
- MP 350, L = 1.95 – 3.50 m
- MP 480, L = 2.60 – 4.80 m
- MP 625, L = 4.30 – 6.25 m

### System dimensions

Assembly heights as individual props according to the permissible extension lengths 0.80 m – 6.25 m or 1.30 m – 6.75 m for use with Base MP 50.

### Technical data

- Approval Z-8.312-824.
- Type test S-N/160206
- For load-bearing capacities, see Tables.

## Intended use

1. PERI products have been designed for exclusive use in the industrial and commercial sectors by suitably trained personnel only.

2. These Instructions for Assembly and Use serve as basis for the project-related risk assessment and the instructions for the provision and use of the system by the contractor (user). However, they do not replace them.

3. Only PERI original components may be used. The use of other products and spare parts represents a misapplication with associated safety risks.

4. The components are to be inspected before each use to ensure that they are in perfect condition and function correctly.

5. Changes to PERI components are not permitted and represent a misapplication with associated safety risks.

6. Safety instructions and permissible loads must be observed at all times.

7. Components provided by the contractor must correspond to the characteristic features required in these Instructions for Assembly and Use as well as all current laws and standards.

In particular, the following applies if nothing else is specified:

- timber components: Strength Class C24 for Solid Wood EN 338.
- scaffold tubes: galvanised steel tubes with minimum dimensions of  $\varnothing$  48.3 x 3.2 mm according to EN 12811-1:2003 4.2.1.2.

– scaffold tube couplings according to EN 74.

8. Deviations from the standard configuration may only be carried out after a separate risk assessment has been completed by the contractor (user). On this basis, appropriate measures for the working safety and stability are to be implemented.



# Introduction

## Safety instructions

### General

1. Deviations from the standard configuration and/or intended use present a potential safety risk.

2. All country-specific laws, standards and other safety regulations are to be taken into account whenever our products are used.

3. During unfavourable weather conditions, suitable precautions and measures are to be taken in order to ensure both working safety and stability.

4. The contractor (user) must ensure the stability throughout all phases of construction. He must ensure and verify that all occurring loads are safely transferred.

5. The contractor (user) has to provide safe working areas for site personnel which can be reached through the provision of safe access means. Areas of risk must be cordoned off and marked. Hatches and openings on accessible working areas must be kept closed during working operations.

6. For better comprehensibility, detailed drawings are partly incomplete. The safety installations which have possibly not been included in these detailed drawings must nevertheless still be available.

### System-specific

1. Retract components only when the concrete has sufficiently hardened and the person in charge has given the approval for striking to take place.

2. Anchoring is to take place only if the anchorage has sufficient concrete strength.

3. After exceptional occurrences or long periods of downtime at the location where the formwork or shoring is used, the unit and its components must be checked for stability and functionality.

### Care and maintenance

1. MULTIPROP Slab Props have been designed for long-term use on the construction site.

2. In order to maintain the value and operational readiness of the MULTIPROP Slab Props over a long period of time, the props should be carefully handled at all times.

3. Occasionally grease the rubbing plate to ensure easier handling.

4. Only PERI qualified personnel are allowed to carry out repairs on the MULTIPROP Slab Props.

### Storage and transportation

1. Do not drop the components.

2. Store and transport components ensuring that no unintentional change in their position is possible. Detach lifting gear from the lowered units only if these are in a stable position and no unintentional change is possible.

3. When moving the components, make sure they are lifted and set down in a way that any unintentional tilting over, falling apart, sliding or rolling away is prevented.

4. Use only suitable load-carrying equipment to move the components as well as the designated load-bearing points.

5. During the lifting and moving procedure, ensure that all loose parts are removed or secured.

6. Assemble and move components on clean, flat and sufficiently load-bearing surfaces only.

---

## General

### Additional PERI product information

Brochure:

- MULTIPROP Aluminium Slab Props

Instructions for Use:

- Pallets and Stacking Devices

PERI design tables

Type tests for:

- MULTIPROP Props
- MULTIPROP System
- MULTIPROP Props with Base MP 50
- MULTIPROP System with Base MP 50

Instructions for Assembly and Use:

- MULTIFLEX
- SKYDECK
- TABLE MODULES / SLAB TABLES
- SKYTABLE
- VARIODECK

**The structures shown in these Instructions for Assembly and Use are examples and feature only one component size. They are valid accordingly for all component sizes contained in the standard configuration.**

# A1 Assembly

## Pre-assembling the slab prop



For the safety of the user, the following should be checked before every use to see whether

- the slab prop is complete,
- the slab prop has no cracks, holes or broken parts,
- the inner tube and collar are freely movable and
- the end plates are level.



- Shown here is the assembly of a free-standing MULTIPROP Slab Prop.
- When used in the system, the "MULTIPROP System" Instructions for Assembly and Use must be adhered to.
- The numbers on the integrated measuring tape show the complete length (L) of the MULTIPROP Slab Prop in metres [m], e.g. 1<sub>25</sub> = 1.25 m.
- The complete length of the MULTIPROP Slab Prop can be read at the top edge of the collar (4a).
- Adjusting range per complete turn: 36 mm.
- The prop can be continuously readjusted by means of the adjusting collar if partially loaded up to 15 kN.




Fig. A1.01a




Fig. A1.01b

### Preparation

MULTIPROP Slab Props are delivered with retracted inner tubes in a Pallet RP-2 as standard.

Place the prop on an available work trestle or the Pallet RP-2.

(Fig. A1.01a + A1.01b)



# A1 Assembly

## Rough adjustment of the extension length

1. Press down safety hook (3).
- > Inner tube (2) together with the adjusting collar (4) is released.
- (Fig. A1.02a)
2. Pull out inner tube until the length indicated on the measuring tape (6) is slightly more than the required prop length.
3. Turn the adjusting collar until the required extension length is reached.




Fig. A1.02a



Position	Turn adjusting collar	"L" is:
<b>Outer tube bottom</b> (Fig. A1.02b)	anti-clock-wise	smaller
	clockwise	larger
<b>Inner tube bottom</b> (Fig. A1.02c)	anti-clock-wise	larger
	clockwise	smaller


4. Push in the inner tube until the adjusting collar lies against the rubbing plate (7).
- > Safety hook locks the inner tube in position.
5. Fine adjustment of adjusting collar (4) to specified length.



Is the safety hook engaged?



Quick adjustment of the smooth-running adjusting collar is carried out by "fast spindling".



Outer tube bottom  
Fig. A1.02b

Inner tube bottom  
Fig. A1.02c

# A1 Assembly

## Assembly with Universal Tripod

For slab props with tube  $\varnothing$  48 mm to  $\varnothing$  120 mm.



### Slab Props and Tripods

- place on clean, flat and sufficiently load-bearing surface only!
- are not suitable for planned transfer of horizontal loads!



- Shown here is the assembly of a free-standing slab prop.
- When used in the system, the respective Instructions for Assembly and Use are to be taken into account.
- Universal Tripods (9) are pure assembly aids for shuttering and striking up to heights of approx. 3 m.

### Universal Tripod assembly

1. Insert pre-assembled slab prop into the Universal Tripod (9).  
(Fig. A1.03)

2. Tighten clamp (9a).  
Ensure that the slab prop lies flat against the top and bottom connection plates (9b and 9c).  
(Fig. A1.03)



- Does the slab prop lie flat to the top and bottom connection plates?
- Has the clamp been tightened?
- Is the slab prop in a perpendicular position?




Fig. A1.03

## Releasing the slab prop under load



**For loads > 60 kN, use the Wing Nut Spanner HD!**

### Dismantling:

1. Release adjusting collar and set load-free with:
  - hammering the lowering cam. (Fig. A2.01a)
  - Wing Nut Spanner HD Item no. 022027. (Fig. A2.01b)
2. Remove slab prop.
3. Dismantle slab prop.
  - Press down safety hook.
  - > Inner tube with adjusting collar is disengaged.
  - Pull out inner tube a short distance and spindle adjusting collar back to the end plate.
  - Push in the inner tube until the adjusting collar lies against the rubbing plate.
  - > Safety hook locks the inner tube in position.
4. Place slab prop in the pallet.



See Section A5 "Storage and Transportation".



The Wing Nut Spanner HD facilitates energy-saving and noiseless loosening of the adjusting collar – even if the props are placed under maximum load. Max.  $F = 0.95 \text{ kN}$ .

Outer tube bottom





Fig. A2.01a



Outer tube bottom





Fig. A2.01b



# A3 Accessories

## Brace Clamp

Item no. 027790

Used as an alternative assembly aid with high slab props as of approx. 4 m using bracing boards 3 x 15 cm.



**Brace Clamps are not suitable for a planned transfer of horizontal loads!**



- Brace Clamps (10) are simply assembly aids for shuttering and striking procedures.
- As an option, universal tripods can be used as additional assembly aids.

### Assembly

1. Pull the narrow side of the wedge (10a) out of the clamp.
2. Place Brace Clamp (10) around the tube of the slab prop.
3. Insert board in the open side of the clamp.
4. Put wedge back into recess of the clamp and hammer in securely.  
→ The wedge secures the board.
5. Mount additional bracing boards by means of Brace Clamps.  
(Fig. A3.01)



- Are the slab props in a perpendicular position?
- Are all wedges securely fixed?
- Have all wedges secured the boards?




Fig. A3.01

**Base MP 50**



**Take into account separate tables with permissible prop load!**

- Used for extending the slab prop by 50 cm.
- Automatic centering of the slab prop by means of centering pins.
- Two clamping claws connect the Base MP 50 with the slab prop.
- The MULTIPROP Slab Prop can be mounted on the Base MP 50 with the inner or outer tube.

**Assembly**

1. Place the slab prop on the head plate (11a) of the Base MP 50 that the two centering pins (11b) lock into the holes of the end plate.
2. Position clamping claws (11c) with the hammer on the end plate of the slab prop. Base MP 50 (11) is now connected to the prop. (Fig. A3.02)



Are the two clamping claws fully set on the end plate?



Through the use of the Base MP 50, the same type of prop can be used at different heights.

**Dismantling**

Release clamping claws with a hammer.




Fig. A3.02

# A4 Foreseeable misapplications



**Applications of this type or similar are prohibited!**

**Do not use slab props with broken or damaged nuts!**




Fig. A4.01a

**Do not use slab props with bent end plates or split weld seams on the end plates!**




Fig. A4.01b

**Do not use slab props with bent abrasive plates!**




Fig. A4.01c

**Ensure that slab props are always in a perpendicular position!**




Fig. A4.02a

**Only use full-faced support surfaces!**




Fig. A4.02b




Fig. A4.02c



Slab props must always be in a vertical position.



End plates of the slab props must always lie completely flat. If necessary, fill the gap and secure the wedge.

# A4 Foreseeable misapplications



**Applications of this type or similar are prohibited!**

**Non-loadable installation surface!**




Fig. A4.03a




Fig. A4.03b



Slab props must always be positioned on load-bearing and flat surfaces.

**Do not connect the slab props to each other!**




Fig. A4.04

**Do not use with Tilting Forkhead MKK or Tilting Base MKF!**




Fig. A4.05

**Do not use for supporting formwork elements!**




Fig. A4.06



If the clearance is too large, a longer slab prop or shoring tower must be used, e.g. MULTIPROP System with MRK Frames.



Use designated support equipment, e.g. push-pull props or brace frames.

# A4 Foreseeable misapplications



**Applications of this type or similar are prohibited!**

**Do not use as a trench strut!**




Fig. A4.07

**Do not use as anti-fall protection!**




Fig. A4.08

**Do not use as a guardrail holder!**




Fig. A4.09



Use designated trench strut.



Use designated anti-fall protection, e.g. PROKIT EP 110 or EP 200.



Use designated anti-fall protection, e.g. PROKIT EP 110 or EP 200.



# A5 Storage and Transportation



- **Instructions for Use for PERI Pallet and Stacking Devices must be followed at all times!**
- **Follow PERI packaging guidelines!**
- **Transportation units must be correctly stacked and secured!**

PERI Pallets (14) are suitable for lifting by a crane or forklift. When using a crane, 4-sling lifting gear is used to move the pallets. During fork-lift operations, the pallets can be moved either by a fork-lift truck or by using the PERI Lifting Trolley. All pallets can be lifted using the longitudinal as well as front sides. Max. number of pallets in accordance with packaging guidelines.



The safety hook (3) prevents the inner tube (2) from slipping out and must be engaged.

## Storage



**Store and transport slab props of the same size! (Fig. A5.01 + A5.02)**

## Transportation



- **Ensure loads are correctly secured during transport!**
- **Use tension belts or steel bands.**

The number of pallets that can be transported depends on the respective national transport regulations.




Fig. A5.01

Example: MULTIPROP Slab Props positioned horizontally in a Pallet RP-2 and secured by means of a tension belt.




Fig. A5.02

Example: MULTIPROP Slab Props stacked using battens and secured by means of a steel band.

# Table MULTIPROP 120, 250, 350

## Permissible prop load [kN] according to the type test

Extension length [cm]	MP 120 L = 0.80 – 1.20 m		MP 250 L = 1.45 – 2.50 m		MP 350 L = 1.95 – 3.50 m	
	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom
80	89.3	102.0				
90	89.0	102.0				
100	88.7	102.0				
110	88.7	98.0				
120	88.7	94.0				
130						
140						
150			99.3	94.0		
160			99.3	94.0		
170			99.3	94.0		
180			97.2	94.0		
190			92.9	94.0		
200			88.7	94.0	96.0	94.7
210			86.5	94.0	93.1	94.7
220			84.4	94.0	90.1	94.7
230			82.5	92.4	87.5	94.1
240			80.9	89.2	85.1	93.1
250			79.3	86.0	82.7	92.0
260					79.3	88.7
270					76.0	85.3
280					73.3	82.7
290					70.7	80.0
300					68.7	77.0
310					66.7	74.0
320					63.1	71.0
330					59.6	68.0
340					54.7	61.5
350					49.8	54.9

Permissible load-bearing capacity (DIN EN 16031)

### Note:

Use Spanner HD to release loads > 60 kN,  
Art.-no. 022027.

# Table for MULTIPROP 480, 625

**Permissible prop load [kN] according to the type test**

Extension length [cm]	MP 480 L = 2.60 – 4.80 m		MP 625 L = 4.30 – 6.25 m	
	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom
260	88.7	94.0		
270	87.8	92.3		
280	87.0	90.7		
290	86.2	89.0		
300	85.3	87.3		
310	80.2	84.9		
320	75.1	82.5		
330	70.0	80.0		
340	66.6	77.3		
350	63.2	74.7		
360	59.7	72.0		
370	56.2	67.4		
380	52.8	62.7		
390	49.3	58.1		
400	46.3	54.1		
410	43.3	50.0		
420	40.3	45.9		
430	38.0	43.3	57.9	45.7
440	35.7	40.8	56.3	45.7
450	33.5	38.2	54.7	45.7
460	31.2	35.6	52.5	45.1
470	28.9	33.1	50.2	44.5
480	26.7	30.5	47.8	43.6
490			45.1	42.5
500			42.4	41.3
510			39.8	39.9
520			37.2	38.5
530			34.9	37.0
540			32.9	35.6
550			30.9	34.1
560			29.3	32.6
570			27.7	31.1
580			26.3	29.5
590			25.0	27.9
600			23.7	26.2
610			22.6	24.8
620			21.5	23.4
625			21.0	22.7

Permissible load-bearing capacity (DIN EN 16031)

**Note:**

Use Spanner HD to release loads > 60 kN,  
Art.-no. 022027

# Table MULTIPROP 120, 250, 350 with Base MP 50

**Permissible prop load [kN] according to the type test**

Overall height [cm] (prop extension + 50 cm)	MP 120 + MP 50 L = 1.30 – 1.70 m		MP 250 + MP 50 L = 1.95 – 3.00 m		MP 350 + MP 50 L = 2.45 – 4.00 m	
	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom
130	88.0	84.7				
140	88.0	83.3				
150	88.0	82.0				
160	86.3	80.3				
170	84.7	78.7				
180						
190						
200			89.3	94.0		
210			89.3	94.0		
220			89.3	94.0		
225			89.3	94.0		
230			88.1	93.7		
240			85.7	93.2		
250			83.3	92.7	88.7	85.3
260			79.9	88.9	88.7	85.3
270			76.4	85.2	88.7	85.3
280			72.9	80.5	86.4	85.3
290			69.3	74.9	81.9	85.3
300			65.7	69.3	77.3	85.3
310					73.3	82.3
320					69.3	79.3
330					65.6	72.1
340					61.8	64.9
350					57.4	60.7
360					53.1	56.4
370					49.4	52.2
380					45.7	48.0
390					42.4	44.0
400					39.1	40.0

Permissible load-bearing capacity (DIN EN 16031)

**Note:**

Use Spanner HD to release loads > 60 kN,  
Art.-no. 022027.

# Table for MULTIPROP 480, 625 with Base MP 50

## Permissible prop load [kN] according to the type test

Overall height [cm] (prop extension + 50 cm)	MP 480 + MP 50 L = 3.10 – 5.30 m		MP 625 + MP 50 L = 4.80 – 6.75 m	
	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom
310	88.7	81.3		
320	86.3	81.0		
330	84.0	80.7		
340	81.7	80.3		
350	79.3	80.0		
360	73.3	75.8		
370	67.2	71.5		
380	61.2	67.3		
390	56.9	62.9		
400	52.6	58.4		
410	48.3	53.9		
420	45.5	50.1		
430	42.6	46.3		
440	39.8	42.5		
450	37.6	40.0		
460	35.5	37.5		
470	33.3	35.0		
480	31.7	33.2	48.7	44.5
490	30.0	31.4	47.5	44.4
500	28.4	29.6	46.3	44.3
510	26.8	27.8	44.6	43.1
520	25.1	26.1	42.9	41.8
530	23.5	24.3	41.1	40.4
540			39.2	38.8
550			37.3	37.1
560			35.3	35.6
570			33.3	34.0
580			31.5	32.5
590			29.8	31.0
600			28.1	29.5
610			26.7	28.1
620			25.3	26.7
630			24.1	25.4
640			22.9	24.2
650			21.8	22.9
660			20.8	21.8
670			19.8	20.6
675			19.3	20.0

Permissible load-bearing capacity (DIN EN 16031)

### Note:

Use Spanner HD to release loads > 60 kN,  
Art.-no. 022027.

# MULTIPROP Slab Props



Item no.	Weight kg
027288	10.200
027289	15.400
027290	19.500
027291	24.900
027305	34.700

- MULTIPROP MP**
- MULTIPROP MP 120**
- MULTIPROP MP 250**
- MULTIPROP MP 350**
- MULTIPROP MP 480**
- MULTIPROP MP 625**

Slab prop made of aluminium. Used as individual prop as well as in combination with MULTIPROP Frames MRK to form towers.


min. L	max. L
800	1200
1450	2500
1950	3500
2600	4800
4300	6250

**Note**

Approved by the German Building Authorities No. Z-8.312-824.

**Technical Data**

Permissible load: see PERI Design Tables.





028000 9.170

**Universal Tripod, galv.**

Erection aid for slab props with Ø 48 – 120 mm and 120 x 120 mm. Can also be used in combination with MULTIPROP MP slab props and all slab props with Base MP 50.

**Note**

Only use as erection aid!





# MULTIPROP Slab Props



Item no.	Weight kg
027790	2.460

## Brace Clamp HL, galv., 76 – 120 mm



For assembly of 3 x 15 cm stiffening boards at slab props  $\varnothing$  76 – 89 mm and 100 x 100 mm to 120 x 120 mm.



022027	3.600
--------	-------

## Wing Nut Spanner HD


For easy release of the Head Spindle HDK 45, the Head Spindle TR 110-80/55 and the MULTIPROP slab prop.



027310	8.900
--------	-------


## Base MP 50

For use with slab props with an end plate thickness of 6 – 10 mm. With clamped quick-release fastener.



### Note

Permissible load: see PERI Design Tables.



# MULTIPROP Slab Props



Item no. Weight kg

103434	38.500
103429	45.300

**Pallets RP-2, galv.**

**Pallet RP-2 80 x 120, galv.**

**Pallet RP-2 80 x 150, galv.**



For stacking and transportation of formwork and scaffolding components.

## Note

Follow Instructions for Use!

## Technical Data


Permissible load-bearing capacity 1.5 t.







# PERI International



## North America

- CA** Canada  
PERI Formwork Systems, Inc.  
[www.peri.ca](http://www.peri.ca)
- MX** Mexico  
PERI Cimbras y Andamios, S.A. de C.V.  
[www.peri.com.mx](http://www.peri.com.mx)
- PA** Panama  
PERI Panama Inc.  
[www.peri.com.pa](http://www.peri.com.pa)
- US** USA  
PERI Formwork Systems, Inc.  
[www.peri-usa.com](http://www.peri-usa.com)

## South America

- AR** Argentina  
PERI S.A.  
[www.peri.com.ar](http://www.peri.com.ar)
- BR** Brazil  
PERI Formas e Escoramentos Ltda.  
[www.peribrasil.com.br](http://www.peribrasil.com.br)
- CL** Chile  
PERI Chile Ltda.  
[www.peri.cl](http://www.peri.cl)
- CO** Colombia  
PERI S.A.S.  
[www.peri.com.co](http://www.peri.com.co)
- PE** Peru  
PERI Peruana S.A.C.  
[www.peri.com.pe](http://www.peri.com.pe)

## Africa

- AO** Angola  
Pericofragens, Lda.  
[www.peri.pt](http://www.peri.pt)
- DZ** Algeria  
S.A.R.L. PERI  
[www.peri.dz](http://www.peri.dz)
- BW** Botswana  
PERI (Proprietary) Limited  
[www.peri.co.bw](http://www.peri.co.bw)
- EG** Egypt  
Egypt Branch Office  
[www.peri.com.eg](http://www.peri.com.eg)
- MA** Morocco  
PERI S.A.  
[www.peri.ma](http://www.peri.ma)
- MZ** Mozambique  
PERI (Pty.) Ltd.  
[www.peri.co.mz](http://www.peri.co.mz)
- NA** Namibia  
PERI (Pty.) Ltd.  
[www.peri.na](http://www.peri.na)
- NG** Nigeria  
PERI Nigeria Ltd.  
[www.peri.ng](http://www.peri.ng)
- TN** Tunisia  
PERI S.A.U.  
[www.peri.es](http://www.peri.es)
- TZ** Tanzania  
PERI Formwork and Scaffolding Ltd  
[www.peri.co.tz](http://www.peri.co.tz)
- ZA** South Africa  
PERI Formwork Scaffolding (Pty) Ltd  
[www.peri.co.za](http://www.peri.co.za)

## Asia

- AE** United Arab Emirates  
PERI (L.L.C.)  
[www.peri.ae](http://www.peri.ae)
- AZ** Azerbaijan  
PERI Representative Office  
[www.peri.com.tr](http://www.peri.com.tr)
- HK** Hong Kong  
PERI (Hong Kong) Limited  
[www.perihk.com](http://www.perihk.com)
- ID** Indonesia  
PT Beton Perkasa Wijaksana  
[www.betonperkasa.com](http://www.betonperkasa.com)
- IL** Israel  
PERI F.E. Ltd.  
[www.peri.co.il](http://www.peri.co.il)
- IN** India  
PERI (India) Pvt Ltd  
[www.peri.in](http://www.peri.in)
- IR** Iran  
PERI Pars. Ltd.  
[www.peri.ir](http://www.peri.ir)
- JO** Jordan  
PERI GmbH – Jordan  
[www.peri.com](http://www.peri.com)
- JP** Japan  
PERI Japan K.K.  
[www.peri.co.jp](http://www.peri.co.jp)
- KR** Korea  
PERI (Korea) Ltd.  
[www.perikorea.com](http://www.perikorea.com)
- KW** Kuwait  
PERI Kuwait W.L.L.  
[www.peri.com.kw](http://www.peri.com.kw)
- KZ** Kazakhstan  
TOO PERI Kazakhstan  
[www.peri.kz](http://www.peri.kz)
- LB** Lebanon  
PERI Lebanon Sarl  
[lebanon@peri.de](mailto:lebanon@peri.de)
- MY** Malaysia  
PERI Formwork Malaysia Sdn. Bhd.  
[www.perimalaysia.com](http://www.perimalaysia.com)
- OM** Oman  
PERI (L.L.C.)  
[www.peri.ae](http://www.peri.ae)
- PH** Philippines  
PERI-Asia Philippines, INC.  
[www.peri.com.ph](http://www.peri.com.ph)
- QA** Qatar  
PERI Qatar LLC  
[www.peri.qa](http://www.peri.qa)
- SA** Saudi Arabia  
PERI Saudi Arabia Ltd.  
[www.peri.com.sa](http://www.peri.com.sa)
- SG** Singapore  
PERI Asia Pte Ltd  
[www.periasia.com](http://www.periasia.com)
- TM** Turkmenistan  
PERI Kalıp ve İşkeleleri  
[www.peri.com.tr](http://www.peri.com.tr)
- TH** Thailand  
Peri (Thailand) Co., Ltd.  
[www.peri.co.th](http://www.peri.co.th)
- VN** Vietnam  
PERI ASIA PTE LTD  
[www.peri.com.vn](http://www.peri.com.vn)

**PERI**

**PERI GmbH**  
**Formwork Scaffolding Engineering**  
Rudolf-Diesel-Strasse 19  
89264 Weissenhorn  
Germany  
Tel. +49 (0)7309.950-0  
Fax +49 (0)7309.951-0  
info@peri.com  
www.peri.com



## Oceania

**AU** Australia  
PERI Australia Pty. Ltd.  
www.periaus.com.au

**NZ** New Zealand  
PERI Australia Pty. Limited  
www.peri.co.nz

## Europe

**AL** Albania  
PERI Kalıp ve İskeleleri  
www.peri.com.tr

**AT** Austria  
PERI Ges.mbH  
www.peri.at

**BA** Bosnia and Herzegovina  
PERI oplate i skele d.o.o  
www.peri.com.hr

**BE** Belgium  
PERI N.V.  
www.peri.be

**BG** Bulgaria  
PERI Bulgaria EOOD  
www.peri.bg

**BY** Belorussia  
IOOO PERI  
www.peri.by

**CH** Switzerland  
PERI AG  
www.peri.ch

**CZ** Czech Republic  
PERI spol. s r.o.  
www.peri.cz

**DE** Germany  
PERI GmbH  
www.peri.de

**DK** Denmark  
PERI Danmark A/S  
www.peri.dk

**EE** Estonia  
PERI AS  
www.peri.ee

**ES** Spain  
PERI S.A.U.  
www.peri.es

**FI** Finland  
PERI Suomi Ltd. Oy  
www.perisuomi.fi

**FR** France  
PERI S.A.S.  
www.peri.fr

**GB** United Kingdom  
PERI Ltd.  
www.peri.ltd.uk

**GR** Greece  
PERI Hellas Ltd.  
www.perihellas.gr

**HR** Croatia  
PERI oplate i skele d.o.o.  
www.peri.com.hr

**HU** Hungary  
PERI Kft.  
www.peri.hu

**IR** Ireland  
Siteserv Access & Formwork  
www.siteservaccess.ie

**IS** Iceland  
Armar ehf.  
www.armor.is

**IT** Italy  
PERI S.r.l.  
www.peri.it

**LT** Lithuania  
PERI UAB  
www.peri.lt

**LU** Luxembourg  
N.V. PERI S.A.  
www.peri.lu

**LV** Latvia  
PERI SIA  
www.peri-latvija.lv

**NL** Netherlands  
PERI b.v.  
www.peri.nl

**NO** Norway  
PERI Norge AS  
www.peri.no

**PL** Poland  
PERI Polska Sp. z o.o.  
www.peri.com.pl

**PT** Portugal  
Pericofragens Lda.  
www.peri.pt

**RO** Romania  
PERI România SRL  
www.peri.ro

**RS** Serbia  
PERI oplate d.o.o.  
www.peri.rs

**RU** Russia  
OOO PERI  
www.peri.ru

**SE** Sweden  
PERI Sverige AB  
www.peri.se

**SI** Slovenia  
PERI oplate i skele d.o.o  
www.peri.com.hr

**SK** Slovakia  
PERI spol. s r.o.  
www.peri.sk

**TR** Turkey  
PERI Kalıp ve İskeleleri  
www.peri.com.tr

**UA** Ukraine  
TOW PERI  
www.peri.ua

**The optimal System  
for every Project and  
every Requirement**



**Wall Formwork**



**Column Formwork**



**Slab Formwork**



**Climbing Systems**



**Bridge Formwork**



**Tunnel Formwork**



**Shoring Systems**



**Construction Scaffold**



**Facade Scaffold**



**Industrial Scaffold**



**Access**



**Protection Scaffold**



**Safety Systems**



**System-Independent Accessories**



**Services**



**PERI GmbH**  
**Formwork Scaffolding Engineering**  
Rudolf-Diesel-Strasse 19  
89264 Weissenhorn  
Germany  
Tel. +49 (0)7309.950-0  
Fax +49 (0)7309.951-0  
info@peri.com  
www.peri.com